Ü
T
Æ
12.00
L
ا المراجعة

SYSTEM AND METHOD FOR CONTROLLING PARAMETERS

IN AN ELECTRONIC IMAGING DEVICE-

3

4

2

BACKGROUND OF THE INVENTION

5 1. Field of the Invention

This invention relates generally to electronic imaging devices and

7 more particularly to a system and method for controlling parameters in an

8 electronic imaging device.

9

10

12

13

18

21

2. <u>Description of the Background Art</u>

11 Effective control of user preferences and system parameters is an

important consideration for users, designers and manufacturers of many

electronic devices and systems. Control of system parameters is

14 particularly important in modern electronic imaging systems (such as

15 digital camera devices) which often feature a substantial number of

16 system parameters that are adjustable depending upon individual user

17 preferences. Examples of such adjustable camera preferences include

selectable exposure settings, image compression ratios, camera flash

19 settings and zoom speed specifications.

20 Efficiently controlling the operating parameters of an electronic

imaging device ideally allows the system user to capture image data of

- 1 maximum quality. However, in order to consistently capture high-quality
- 2 image data, the system for controlling camera operating parameters must
- 3 be both flexible and powerful. System flexibility provides satisfactory
- 4 methods to fulfill user needs and preferences, depending upon the current
- 5 photographic environment. A powerful system results from efficiently
- 6 providing techniques to control the operating parameters in a user-
- 7 friendly and effective manner.
- 8 Some conventional imaging systems have adjustable operating
- 9 parameters which are not retained after a system powerdown occurs. In
- 10 portable imaging systems typically powered by batteries (for example,
- 11 digital cameras), the system must remain constantly powered to retain
- 12 current parameter settings (for example, an exposure setting). A system
- 13 user must therefore risk battery failure at an inopportune moment, or
- 14 repeatedly reset the desired operating parameters each time the imaging
- 15 system is powered up.
- Other conventional imaging systems have the ability to simply set a
- 17 user preference which is then "remembered" as a default value after the
- 18 system is powered down and subsequently powered up again. This
- 19 implementation has a significant disadvantage because the default value is
- 20 altered each time that a particular corresponding preference is adjusted.

- 1 Since the default value directly tracks the current parameter setting, this
- 2 particular implementation is relatively inflexible and ineffective from the
- 3 system user's perspective.
- 4 Still other conventional imaging systems have limited capabilities to
- 5 manipulate the various system operating parameters. For example, such
- 6 imaging systems may lack the ability to selectively restore particular
- 7 system defaults as required by a system user. In other words, the
- 8 command set for controlling user preferences and operating parameters is
- 9 not sufficiently powerful.
- 10 As the foregoing discussion suggests, effective and efficient
- 11 functioning of an electronic imaging device may be enhanced by a flexible
- 12 and powerful approach to controlling operating parameters. Therefore, an
- 13 improved system and method are needed for controlling parameters in an
- 14 electronic imaging device, according to the present invention.

SUMMARY OF THE INVENTION

2	In accordance with the present invention, a system and method are
3	disclosed for controlling parameters in an electronic imaging device. In the
4	preferred embodiment of the present invention, a digital camera includes a
5	set of operating parameters which may be advantageously configured
6	according to the demands of particular photographic environments. To
7	allow system users to flexibly and effectively capture images, the
8	adjustable operating parameters may be stored as parameter values in a
9	series of discrete locations, including a factory defaults location, a user
10	defaults location and a current parameters location. In the preferred
11	embodiment, the factory defaults are stored in a non-volatile memory, the
12	user defaults are stored in an electrically-erasable programmable read-
13	only memory, and the current parameters are stored in a random-access
14	memory. In alternate embodiments, parameter values may readily be
15	stored using various other configurations and implementations.
16	In accordance with the present invention, a parameter manager may
17	control the parameter values stored in the factory defaults location, the
18	user defaults location and the current parameters location. The parameter
19	manager typically controls the stored parameter values in response to a
20	set of commands which may be generated by a central processing unit

- 1 within the digital camera, by an external host computer which may be
- 2 coupled to the digital camera via an input/output interface or by special
- 3 parameter scripts provided on a removable memory device. In the
- 4 preferred embodiment, the above-referenced commands include, but are
- 5 not limited to, a GetState command, a SetState command, a GetDefault
- 6 command, a SetDefault command and a RestoreDefault command.
- 7 The GetState command causes the parameter manager to access and
- 8 send specified current parameters to either the camera's central processing
- 9 unit or to the above-mentioned external command sources. The SetState
- 10 command causes the parameter manager to set selected current
- 11 parameters to a value specified by either the camera's central processing
- 12 unit or by the above-mentioned external command sources.
- The GetDefault command causes the parameter manager to
- 14 selectively access parameter values from either the user defaults or the
- 15 factory defaults and then send the selected parameter values to either the
- 16 camera's central processing unit or to the above-mentioned external
- 17 command sources. The SetDefault command causes the parameter
- 18 manager to set selected user defaults to a value obtained from either the
- 19 camera's central processing unit, the above-mentioned external command
- 20 sources, the current parameters or the factory defaults. The

- 1 RestoreDefault command causes the parameter manager to restore the
- 2 current parameters to values selectively obtained from either the user
- 3 defaults or the factory defaults.
- 4 The factory defaults, the user defaults and the current parameters
- 5 are therefore flexibly and efficiently controlled by the parameter manager
- 6 through the SetState command, the GetState command, the GetDefault
- 7 command, the SetDefault command and the Restore Default command. The
- 8 present invention thus provides an improved system for controlling
- 9 parameters in an electronic imaging device.

BRIEF DESCRIPTION OF THE DRAWINGS

- FIG. 1 is a block diagram of a digital camera, according to the present
- 3 invention;
- 4 FIG. 2 is a block diagram of one embodiment for the imaging device
- 5 of FIG. 1;
- FIG. 3 is a block diagram of one embodiment for the computer of FIG.
- 7 1;

- FIG. 4 is a memory map of one embodiment of the non-volatile
- 9 memory of FIG. 3;
- FIG. 5 is a memory map of one embodiment of the dynamic random-
- 11 access memory of FIG. 3;
- FIG. 6A is an elevation view of one embodiment for the back of the
- 13 FIG. 1 camera;
- FIG. 6B is a plan view of one embodiment for the top of the FIG. 1
- 15 camera;
- FIG. 7 is a memory map of one embodiment for the current
- 17 parameters of FIG. 5;
- FIG. 8A is a block diagram of a basic system for generating
- 19 parameter commands, in accordance with the present invention;

- FIG. 8B is a block diagram of the preferred embodiment for
- 2 controlling parameters in an electronic imaging device, according to the
- 3 present invention;
- 4 FIG. 9 is a flowchart of method steps for a GetState command,
- 5 according to the present invention;
- FIG. 10 is a flowchart of method steps for a SetState command,
- 7 according to the present invention;
- FIG. 11 is a flowchart of method steps for a GetDefault command,
- 9 according to the present invention;
- FIG. 12 is a flowchart of method steps for a SetDefault command,
- 11 according to the present invention; and
- FIG. 13 is a flowchart of method steps for a RestoreDefault command,
- 13 according to the present invention;

1

<u>DETAILED DESCRIPTION OF THE PREFERRED EMBODIMENT</u>

2	The present invention relates to an improvement in electronic
3	imaging devices, including digital cameras. The following description is
4	presented to enable one of ordinary skill in the art to make and use the
5	invention and is provided in the context of a patent application and its
6	requirements. Although the present invention will be described in the
7	context of a digital camera, various modifications to the preferred
8	embodiment will be readily apparent to those skilled in the art and the
9	generic principles herein may be applied to other embodiments. That
10	is, any image capture device with displays images, icons and/or other
. 11	items, could incorporate the features described hereinbelow and that
12	device would be within the spirit and scope of the present invention.
13	Thus, the present invention is not intended to be limited to the
14	embodiment shown but is to be accorded the widest scope consistent
15	with the principles and features described herein.
16	The present invention comprises a system and method for controlling
17	parameters in an electronic imaging device and includes a series of
18	parameter storage locations coupled to the imaging device for containing
19	parameter value sets, a set of parameter commands for controlling the

parameter value sets, and a parameter manager device for executing the

1	set of parameter commands to control the parameters in the electronic
2 .	imaging device, in accordance with the present invention.
3	
4	Referring now to FIG. 1, a block diagram of a digital camera 110
5	for use in accordance with the present invention is shown. Camera 110
6	preferably comprises an imaging device 114, a system bus 116 and a
7	computer 118. Imaging device 114 is optically coupled to an object 112
8	and electrically coupled via system bus 116 to computer 118. Once a
9	photographer has focused imaging device 114 on object 112 and, using
10	a capture button or some other means, instructed camera 110 to
11	capture an image of object 112, computer 118 commands imaging
12	device 114 via system bus 116 to capture raw image data representing
13	object 112. The captured raw image data is transferred over system
14	bus 116 to computer 118 which performs various image processing
15	functions on the image data before storing it in its internal memory.
16	System bus 116 also passes various status and control signals between
17	imaging device 114 and computer 118.
18	
19	Referring now to FIG. 2, a block diagram of one embodiment of
20	imaging device 114 is shown. Imaging device 114 typically comprises a

- lens 220 having an iris, a filter 222, an image sensor 224, a timing
- 2 generator 226, an analog signal processor (ASP) 228, an
- 3 analog-to-digital (A/D) converter 230, an interface 232, and one or
- 4 more motors 234.
- 5 Imaging device 114 captures an image of object 112 via reflected
- 6 light impacting image sensor 224 along optical path 236. Image sensor
- 7 224, which is typically a charge-coupled device (CCD), responsively
- 8 generates a set of raw image data in CCD format representing the captured
- 9 image 112. The raw image data is then routed through ASP 228, A/D
- 10 converter 230 and interface 232. Interface 232 has outputs for controlling
- 11 ASP 228, motors 234 and timing generator 226. From interface 232, the
- 12 raw image data passes over system bus 116 to computer 118.

- Referring now to FIG. 3, a block diagram of one embodiment for
- 15 computer 118 is shown. System bus 116 provides connection paths
- 16 between imaging device 114, electrically-erasable programmable read-
- only memory (EEPROM) 341, an optional power manager 342, central
- processing unit (CPU) 344, dynamic random-access memory (DRAM)
- 19 346, input/output interface (I/O) 348, non-volatile memory 350, and
- 20 buffers/connector 352. Removable memory 354 connects to system bus

- 1 116 via buffers/connector 352. In alternate embodiments, camera 110
- 2 may also readily be implemented without removable memory 354 or
- 3 buffers/connector 352.
- 4 Power manager 342 communicates via line 366 with power
- 5 supply 356 and coordinates power management operations for camera
- 6 110. CPU 344 typically includes a conventional processor device for
- 7 controlling the operation of camera 110. In the preferred embodiment,
- 8 CPU 344 is capable of concurrently running multiple software routines
- 9 to control the various processes of camera 110 within a multi-threading
- 10 environment. DRAM 346 is a contiguous block of dynamic memory
- 11 which may be selectively allocated to various storage functions. LCD
- 12 controller 390 accesses DRAM 346 and transfers processed image data
- to LCD screen 302 for display.
- 14 I/O 348 is an interface device allowing communications to and
- 15 from computer 118. For example, I/O 348 permits an external host
- 16 computer (not shown) to connect to and communicate with computer
- 17 118. I/O 348 also interfaces with a plurality of buttons and/or dials
- 18 304, and an optional status LCD 306, which, in addition to LCD screen
- 19 302, are the hardware elements of the camera's user interface 308.

Non-volatile memory 350, which may typically comprise a 1 . 2 conventional read-only memory or flash memory, stores a set of computer-readable program instructions to control the operation of 3 4 camera 110. Removable memory 354 serves as an additional image 5 data storage area and is preferably a non-volatile device, readily 6 removable and replaceable by a camera 110 user via buffers/connector Thus, a user who possesses several removable memories 354 may 7 8 replace a full removable memory 354 with an empty removable 9 memory 354 to effectively expand the picture-taking capacity of camera 110. In the preferred embodiment of the present invention, 10 removable memory 354 is typically implemented using a flash disk. 11 Power supply 356 supplies operating power to the various 12 components of camera 110. In the preferred embodiment, power 13 supply 356 provides operating power to a main power bus 362 and also 14 15 to a secondary power bus 364. The main power bus 362 provides 16 power to imaging device 114, I/O 348, non-volatile memory 350 and 17 removable memory 354. The secondary power bus 364 provides power to power manager 342, CPU 344 and DRAM 346. 18 Power supply 356 is connected to main batteries 358 and also to 19

14

backup batteries 360. In the preferred embodiment, a camera 110 user

1 may also connect power supply 356 to an external power source.

2 During normal operation of power supply 356, the main batteries 358

3 provide operating power to power supply 356 which then provides the

4 operating power to camera 110 via both main power bus 362 and

5 secondary power bus 364. During a power failure mode in which the

6 main batteries 358 have failed (when their output voltage has fallen

7 below a minimum operational voltage level) the backup batteries 360

8 provide operating power to power supply 356 which then provides the

9 operating power only to the secondary power bus 364 of camera 110.

10

11 Referring now to FIG. 4, a memory map showing one embodiment of

12 non-volatile memory 350 is shown. In the FIG. 4 embodiment, non-

13 volatile memory 350 includes control application 400, toolbox 402, drivers

14 404, kernel 406 and system configuration 408. Control application 400

15 comprises program instructions for controlling and coordinating the

various functions of camera 110. Toolbox 402 contains selected function

17 modules including parameter manager 410, menu dialog manager 414,

18 EEPROM interface 418 and command handler 422.

19 Parameter manager 410 includes software routines which control

20 and coordinate various operating parameters in camera 110, according



- 2 below in conjunction with FIGS. 8-13. Menu dialog manager 414
- 3 includes software routines which coordinate functions related to the
- 4 user interface 308, including displaying information on LCD screen 302
- 5 and handling information input from buttons 304. EEPROM interface
- 6 418 coordinates communications to and from EEPROM 341 via system
- 7 bus 116. Command handler 422 accesses and handles various system
- 8 commands and advantageously provides the commands to the
- 9 appropriate destination within camera 110. Selected commands are
- 10 further discussed below in conjunction with FIGS. 8-13.

Drivers 404 control various hardware devices within camera 110 (for

12 example, motors 234). Kernel 406 provides basic underlying services for

13 the camera 110 operating system. System configuration 408 performs

14 initial start-up routines for camera 110, including the boot routine and

15 initial system diagnostics.

16


17 Referring now to FIG. 5, a memory map showing one embodiment 18 of dynamic random-access-memory (DRAM) 346 is shown. In the FIG. 5 19 embodiment, DRAM 346 includes RAM disk 532, a system area 534, and

working memory 530.

K

RAM disk 532 is a memory area used for storing raw and 1 2 compressed image data and typically is organized in a "sectored" format similar to that of conventional hard disk drives. 3 In the preferred embodiment, RAM disk 532 uses a well-known and standardized file .4 5 system to permit external host computer systems, via I/O 348, to 6 readily recognize and access the data stored on RAM disk 532. System area 534 typically stores data regarding system errors (for example, 7 8 why a system shutdown occurred) for use by CPU 344 upon a restart of 9 computer 118. 10 Working memory 530 includes various stacks, data structures and variables used by CPU 344 while executing the software routines used 11 within computer 118. Working memory 530 also includes input buffers 12 538 for initially storing sets of raw image data received from imaging 13 device 114 for image conversion, and frame buffers 536 for storing data 14 for display on the LCD screen 402, 15

In a preferred embodiment, a conversion process is performed by
a live view generation program, which is stored in non-volatile memory
350 and executed on CPU 344. However, the conversion process can
also be implemented using hardware. Referring again to FIG. 3, during
the execution of the live view generation program (not shown), CPU 344



- 2 performs color space conversion on the data. The conversions process
- 3 performs gamma correction and converts the raw CCD data into either a
- 4 RGB or YCC color format which is compatible with the LCD screen 402.
- 5 After the conversion, CPU 344 stores the image data in frame buffers
- 6 536. The LCD controller 390 then transfers the processed image data
- 7 from the frame buffers to the LCD screen 402 (via an optional analog
- 8 converter) for display.

9 Working memory 346 further contains current parameters 540

10 which preferably include current settings for adjustable parameters in

11 camera 110. Current parameters 540 are further discussed below in

conjunction with FIG. 7 which includes a TABLE I listing examples of

13 preferred current parameters 540.

14

15

16

17

18

19

20

12

FIGS. 6A and 6B are diagrams depicting the preferable hardware components of the user interface 308 of camera 110. FIG. 6A is a back view of camera 110 showing the LCD screen 302, a four-way navigation control button 609, an overlay button 612, a menu button 614, and a set of programmable soft keys 616. FIG. 6B is a top view of camera 110 showing a shutter button 618, and a mode dial 620. The camera may



- 2 622 and 624, a sound record button 626, and zoom-in, zoom-out.
- 3 buttons 626a and 626b.
- 4 The user interface 308 includes several different operating modes
- 5 for supporting various camera functions. However, the modes relevant
- 6 to this description are review mode, menu mode, and capture (record)
- 7 mode. In review mode, the camera 110 supports the actions of
- 8 reviewing camera contents, editing and sorting images, and printing and
- 9 transferring images. In menu mode, the camera 110 allows the user to
- 10 manipulate camera settings and to edit and organize captured images.
- In capture mode, the camera 110 supports the actions of preparing to
- 12 capture an image, and capturing an image through the use of either the
- 13 LCD screen 302 or the status LCD 306.
- 14 The user switches between the review, menu, and capture modes,
- using the mode dial 620. When the camera is placed into a particular
- 16 mode, that mode's default screen appears in the LCD screen 302 in
- 17 which a set of mode-specific items, such as images, icons, and text, are
- 18 displayed.

A

- 1 Referring now to FIG. 7, a memory map of one embodiment for
- 2 current parameters 540 of FIG. 5A is shown. Current parameters 540
- 3 comprise parameter 1 (710 (a)) through parameter "N" (710(d)) which
- 4 each preferably include, but are not limited to, current settings for
- 5 various operational and functional attributes of camera 110. Specific
- 6 preferred examples for parameter 1 (710(a)) through parameter "N"
- 7 (710(d)) are provided and described below in TABLE I. However,
- 8 various other parameters not listed in TABLE I may readily be
- 9 implemented in alternate embodiments of the present invention.



TABLE I:

	PNAME	DESCRIPTION	VALUE TYPE	VALUE RANGE		
	xmod	Exposure mode specification	UInteger List	1= Auto 2= Shutter priority 3= Aperture priority 4= Gain priority 5= Manual		
	fmod	Focus mode specification	UInteger List	1= Auto 2= Program 3= Manual		
	smod	Strobe mode specification	UInteger List	0= Off 1= Auto 2= Fill 3= Slave 4= Sync		
	zpos	Zoom position specification	UInteger List	100=1X (no zoom) 200=2X 300=3X		
- C	shut	Shutter speed specification; measured in steps, with 16666 being equivalent to 1/60 second	UInteger	125 through 4000000		
	fdst	Focus distance specification; measured in centimeters, with 65535 being infinity	UInteger	30 through 65535		

1 Referring now to FIG. 8A, a block diagram of a basic system for

2 generating parameter commands in camera 110 is shown, in accordance

3 with the present invention. The FIG. 8A system includes removable

4 memory 354 (FIG. 3), parameter manager 410, menu dialog manager

5 414, an external host computer 850, and LCD screen 302 and

6 buttons/dials 304 (both from user interface 308 of camera 110).

7 Parameter manager 410 includes software routines which

8 advantageously control and coordinate various operating parameters in

9 camera 110, in accordance with the present invention. Parameter

10 -manger, 410 preferably functions in response to a set of parameter

11 commands which are described below in conjunction with FIGS. 8B

12 through 13. The parameter commands may be generated from several

13 different sources to provide greater flexibility in camera 110. In the

14 preferred embodiment, the parameter commands may be generated

15 directly from user interface 308 of camera 110, from an external host

16 computer 850, or from special parameter scripts 862 provided on

17 removable memory 354 in camera 110.

For example, camera 110 includes menu dialog manager 414

19 which communicates with parameter manager 410 via line 858 to

20 display parameter information on LCD screen 302 via line 864. A

 $\stackrel{\sim}{\sim}$ 21

1 system user may then use buttons/dials 304 to initiate parameter

2 commands via line 856 and to subsequently interact with selected

3 parameters in camera 110.

4 Furthermore, external host computer 850 may communicate with

5 parameter manager 410 via line 852 to initiate parameter commands

6 and to subsequently interact with selected parameters in camera 110.

7 In addition, removable memory 354 in camera 110 may be flexibly

8 programmed with special parameter scripts 862 that a system user can

9 then selectively execute to initiate and control parameter commands via

10 line 860.

11

12

13

14

15

16

17

18

19

20


Referring now to FIG. 8B, a block diagram of the preferred embodiment for controlling parameters in camera 110 is shown, according to the present invention. The FIG. 8B embodiment includes current parameters 540 (described above in conjunction with FIGS. 5 and 7), user defaults 810 and factory defaults 812. User defaults 810 are adjustable parameter settings which are preferably stored in EEPROM 341 and thus are retained even when camera 110 is powered down. Factory defaults 812 are fixed parameter settings which are

preferably stored in non-volatile memory 350 of camera 110.

In alternate embodiments, current parameters 540, user defaults

- 2 810 and factory defaults 812 may also be readily implemented using
- 3 various other hardware and/or software configurations, in accordance
- 4 with the present invention. Furthermore, in alternate embodiments, the
- 5 present invention may include various other parameter storage
- 6 locations in addition to (or instead of) current parameters 540, user
- 7 defaults 810 and factory defaults 812.
- 8 Like current parameters 540, user defaults 810 and factory
- 9 defaults 812 may also be configured to include a parameter 1 (710(a))
- through a parameter "N" (710(d), as shown above in the FIG. 7 diagram.
- 11 Furthermore, user defaults 810 and factory defaults 812 may include
- 12 the parameter examples provided in TABLE I above, or may alternately
- include various other parameters not specifically listed in TABLE I.
- 14 Camera 110 preferably loads user defaults 810 into current
- 15 parameters 540 during or following each power up sequence so that
- 16 camera 110 typically starts up with parameter values from user
- 17 defaults 810. However, when camera 110 is initially powered up after
- 18 manufacture, the user defaults 810 have not yet been set by a system
- 19 user. Therefore, factory defaults 812 from non-volatile memory 350
- are preferably loaded into user defaults 810 within EEPROM 341.

- 1 Camera 110 thus initially starts up with parameter values from factory
- 2 defaults 812.
- 3 Camera 110 uses parameter manager 410 to advantageously
- 4 control and/or access values stored in current parameters 350, user
- 5 defaults 810 and factory defaults 812. In the preferred embodiment,
- 6 parameter manager 410 operates in response to a set of commands
- 7 which include, but are not limited to, a GetState command 816, a
- 8 SetState command 818, a GetDefault command 822, a SetDefault
- 9 command 828 and a RestoreDefault command 836. Each of the above
- 10 commands includes one or more command parameters which, in the
- 11 following discussion, are bracketed with parentheses for clarity.
- The GetState command 814 sends (PName) to request one or more
- 13 current settings of current parameter(s) 540. The (PName) corresponds
- 14 to a specific parameter of camera 110. In the preferred embodiment, it
- 15 may be a symbolic name as shown in TABLE I, or in alternate
- 16 embodiments, (PName) may simply be a number. In response,
- 17 parameter manager 410 sends the specified current parameter(s) 540
- to the source of the GetState command 814 via path 816. Only if
- 19 (PName) is NULL does parameter manager 410 return all current



- 2 current parameter(s) 540 to the source of the GetState command 814.
- The SetState command 818 on path 820 preferably sends
- 4 (PNameValueStruct) to change one or more current settings of current
- 5 parameters 540. Parameter manager 410 then sets the designated
- 6 current parameter 540 to a value specified in (PNameValueStruct).
- 7 Either the user of camera 110 or an external source may generate the
- 8 SetState command 818 to advantageously update current parameters
- 9 540.
- The GetDefault command 822(a) sends (DefaultSource, PName) to
- 11 request one or more parameter settings from user defaults 810. The
- 12 GetDefault command 822(b) sends (DefaultSource, PName) to request
- one or more parameter settings from factory defaults 812.
- 14 (DefaultSource) specifies whether to utilize user defaults 810 or factory
- 15 defaults 812 as a source. In response, parameter manager 410 either
- sends the specified user default(s) 810 via path 824, or sends the
- 17 specified factory defaults 812 via path 826. If (PName) is NULL, then
- 18 parameter manager 410 returns all parameters from the selected
- 19 source. Parameter manager 410 then provides the specified parameter
- 20 values to either the user of camera 110 or to an external command

- 1 source (depending on which device generated the GetDefault command
- 2 822(a) or 822(b)).
- The SetDefault command 828 preferably sends (UpdateSource,
- 4. PNameValueStruct) to change one or more current settings of user
- 5 defaults 810. (UpdateSource) indicates which source is used to update
- 6 user defaults 810. Parameter manager 410 sets the designated user
- 7 default(s) 810 specified in (PNameValueStruct). Either the user of
- 8 camera 110 or an external source may generate the SetDefault
- 9 command 828(a) on path 830 to cause values set with the command to
- 10 be stored as user defaults 810. SetDefault command 828(b) on path
- 11 832 causes parameter manager 410 to set the designated user
- default(s) 810 using current parameters 540 as a source. SetDefault
- 13 command 828(c) on path 834 causes parameter manager 410 to set the
- 14 designated user default(s) 810 using factory defaults 812 as a source.
- The RestoreDefault command 836 preferably sends
- 16 (DefaultSource, PName) to change one or more current settings of
- 17 current parameters 540. The RestoreDefault command 836 causes
- 18 parameter manager 410 to restore the designated current parameter(s)
- 19 540 to the current value of the specified source. (DefaultSource)
- 20 indicates which source is used to restore current parameters 540.

1	The	RestoreDefault	command	836(a)	On (nath	838	causes
1	1110	RestoreDeraum	Command	0.50(a)	, 011	pam	020	causes

- 2 parameter manager 410 to restore the designated current parameter(s)
- 3 540 with user defaults 810 as a source. The RestoreDefault command
- 4 828(b) on path 840 causes parameter manager 410 to restore the
- 5 designated current parameter(s) 540 using factory defaults 812 as a
- 6 source. If (PName) is NULL, then all values in current parameters 540
- 7 are preferably restored to the values in the selected source.
- 8 In addition to the foregoing examples, the present invention may
- 9 also readily include various other parameter commands. For example,
- 10 the present invention preferably includes a GetCapabilities command
- 11 which advantageously retrieves information, capabilites and
- 12 permissable values for selected parameters that are supported in
- 13 camera 110.
- The current parameters 540, user defaults 810 and factory
- 15 defaults 812, in combination with GetState command 816, SetState
- 16 command 818, GetDefault command 822, SetDefault command 828 and
- 17 RestoreDefault command 836 thus provide a flexible and effective
- 18 system for controlling parameters in camera 110, according to the
- 19 present invention.

Referring now to FIG. 9, a flowchart of method steps for a GetState 1 command 814 is shown, according to the present invention. 2 910, parameter manager 410 receives a GetState command 814 from 3 either a user of camera 110 or from an external command source. 4 5 in step 911, parameter manager 410 determines whether (PName) 6 within the GetState command is a valid parameter name for camera If so, parameter manager 410, in step 912, determines whether 7 110. (PName) within the GetState command 814 is a NULL value. If (PName) 8 9 is not NULL, then parameter manager 410, in step 914, gets and sends 10 the specified current parameter 540 to the source of the GetState command 814. If (PName) is NULL, then parameter manager 410, in 11 12 step 916, gets and sends all current parameters 540 to the source of the GetState command 814.

14

15

16

17

18

Referring now to FIG. 10, a flowchart of method steps for a SetState command 818 is shown, according to the present invention. step 1010, parameter manager 410 receives a SetState command 818 from either a user of camera 110 or from an external command source. In step 1012, parameter manager 410 selects the appropriate 19

- 1 parameter type based on the (PNameValueStruct) within the SetState
- 2 command 818.
- 3 If the parameter type of step 1012 is a 32-byte string or a 4-
- 4 character string, then the FIG. 10 process goes directly to step 1018.
- 5 However, if the parameter type is a value range of numbers, then
- 6 parameter manager 410, in step 1014, determines whether the value
- 7 specified in the SetState command 818 is within the defined range for
- 8 that parameter. If within the specified range, then step 1014 proceeds
- 9 to step 1018. If not within the specified range, then an error is
- 10 indicated in step 1016. Likewise, if the parameter type is a list of
- 11 values, then parameter manager 410, in step 1020, determines whether
- 12 the value specified in the SetState command 818 is on the defined list
- 13 for that parameter. If on the defined list, then step 1020 proceeds to
- 14 step 1018. If not on the defined list, then and error is indicated in step
- 15 1016. In step 1018, parameter manager 410 then sets the specified
- 16 current parameter 540 to the value specified in the SetState command
- 17 818.
- In the preferred embodiment, parameter manager 410
- 19 advantageously refers to a resource file to obtain necessary parameter
- 20 information from a parameter database. The resource file may include,

but is not limited to, information like factory defaults, parameter types

2 and parameter values (such as ranges or lists).

3

4 Referring now to FIG. 11, a flowchart of method steps for a

5 GetDefault command 822 is shown, according to the present invention.

6 In step 1110, parameter manager 410 receives a GetDefault command

7 822 from either a user of camera 110 or from an external command

8 source. In step 1112, parameter manager 410 selects user defaults 810

9 or factory defaults 812 as a source, depending on a (DefaultSource)

10 within the GetDefault command 822.

11 Then, in step 1113, parameter manager 410 determines whether

12 (PName) within the GetDefault command is a valid parameter name for

13 camera 110. If so, parameter manager 410, in step 1114, determines

14 whether (PName) within the GetDefault command 822 is a NULL value.

15 If (PName) is not NULL, then parameter manager 410, in step 1116,

16 gets and sends the value of the specified parameter from the selected

17 source (user defaults 810 or factory defaults 812). If (PName) is NULL,

18 then parameter manager 410, in step 1118, gets and sends the values of

19 all parameters from the selected source (user defaults 810 or factory

20 defaults 812).

17

18

19

20

1

2


3

4	In step 1210, parameter manager 410 initially receives a SetDefault
5	command 828 and responsively determines whether the Pname is valid
6	in step 1211. If the PName is valid, then parameter manager 410, in
7	step 1212, determines the source of updating information from
8	(UpdateSource) within SetDefault command 828. If the source is
9	external (from either CPU 344 within camera 110 or from an external
10	command source), then the FIG. 12 process goes directly to step 1214.
11	However, if parameter manager 410, in step 1212, determines
12	that user defaults 810 or factory defaults 812 are designated as the
13	updating source, then parameter manager 410, in step 1216,
14	determines whether (PName) within the SetDefault command 828 is a
15	NULL value. If (PName) is not NULL, then parameter manager 410, in


designated as the step 1216, command 828 is a eter manager 410, in step 1214, sets the specified parameter using the selected source (external, user defaults 810 or factory defaults 812). If (PName) is NULL, then parameter manager 410, in step 1218, sets all parameters using the selected source (user defaults 810 or factory defaults 812).

Referring now to FIG. 12, a flowchart of method steps for a

SetDefault command 828 is shown, according to the present invention.



- 2 RestoreDefault command 836 is shown, according to the present
- 3 invention. In step 1310, parameter manager 410 initially receives a
- 4 RestoreDefault command 836. In step 1312, parameter manager 410
- 5 selects user defaults 810 or factory defaults 812 as a source, depending
- 6 on a (DefaultSource) within the RestoreDefault command 836.
- 7 Then, in step 1313, parameter manager 410 determines whether
- 8 (PName) within the RestoreDefault command is a valid parameter name
- 9 for camera 110. If so, parameter manager 410, in step 1314,
- 10 determines whether (PName) within the RestoreDefault command 836
- is a NULL value. If (PName) is not NULL, then parameter manager 410,
- in step 1316, restores current parameters 540 to the specified
- parameter from the selected source (user defaults 810 or factory
- 14 defaults 812). If (PName) is NULL, then parameter manager 410, in
- 15 step 1318, restores all parameters in current parameters 540 using the
- selected source (user defaults 810 or factory defaults 812).
- 17 The invention has been explained above with reference to a
- 18 preferred embodiment. Other embodiments will be apparent to those
- 19 skilled in the art in light of this disclosure. For example, the present
- 20 invention may readily be implemented using configurations other than



- 2 present invention may effectively be used in conjunction with systems
- 3 other than the one described above as the preferred embodiment.
- 4 Therefore, these and other variations upon the preferred embodiments
- 5 are intended to be covered by the present invention, which is limited
- 6 only by the appended claims.